



DGLP/F & DGLI/F

PROXIMITY READER

W I R I N G D I A G R A M



Warning
Do not use a switching power supply because of the interference radiation that may disturb the reading of the badges

Raccordement du lecteur auxiliaire

Terminal

12 ---- Input Voltage 12VAC/DC

V ---- Input Voltage 12VAC/DC

1 ---- Data

4 ---- Common

5 ---- Red LED

3 ---- Green LED

For a correct installation, use the mounting supplied with the reader.
Drill a 5 MM holes and a 35 MM depth minimum.